

PVT Standard ISO Test Instructions

phigenics
Analytical Services
Laboratory

ISO Spread Plate Method 11731 for Legionella — MB-1000

IMPORTANT: Perform and ship this test ONLY on Monday, Tuesday, Wednesday, or Thursday

GATHER MATERIALS
One water sample location requires the following items found in the sample box:

[] Chain of Custody (CoC)



[] 250 mL Sterile Sample Bottle With neutralizing powder

(Sodium Thiosulfate). Do not remove.



[] Security Seal



[] Shipping Label (Fedex Priority Overnight)

In addition to the supplied items (above) you will need:

[] Packing Tape

[] Permanent Marker and Ballpoint Pen

[] Gloves [] Safety Glasses (Required)

Phigenics Analytical Services Laboratory 35701 West Ave, Suite 100 · Warrenville, IL 60555 844-850-4087 | phigenics.com Copyright©2021 Phigenics, LLC

LABEL SAMPLE CONTAINERS

Using a permanent marker, label the top of each bottle lid with the number that corresponds to the CoC "Field ID" for the specific sample location.

COLLECT WATER SAMPLE

IMPORTANT: Gloves and safety glasses are required to be worn.
Fill 250 mL sterile sample bottle to neck of bottle with water from source to be tested. Close bottle tightly and briefly shake (5-10 seconds) to dissolve neutralizing powder.

APPLY SECURITY SEALS and COMPLETE COC

Apply security seal to 250 mL sample bottle over side of cap to side of container exactly as shown. A signed and complete CoC is required for all samples submitted. Using a ballpoint pen, fill out the CoC with specific sample location information. Include the sample ship date and sign in the "Relinquished By" box at the bottom of the page.

REPACK and SHIP on SAME DAY

For assurance of safety in shipping, repack water sample bottle upright (lid up) in sample box as shown in the photo. Place signed and complete CoC in the sample box. Replace top foam layer securely over contents. Close and seal lid with packing tape. Attach Priority Overnight shipping label.



250 mL Water Sample Bottles

Updated — 01/2021



PVT Standard ISO Test Instructions

ISO Spread Plate Method 11731 for Legionella — MB-1000

IMPORTANT: Perform and ship this test ONLY on Monday, Tuesday, Wednesday, or Thursday

GATHER MATERIALS
One water sample location requires the following items found in the sample box:



[] Chain of Custody (CoC)



PVÍ

[] Security Seal



[] Shipping Label (Fedex Priority Overnight)

In addition to the supplied items (above) you will need:

[] Packing Tape [] Gloves [] Permanent Marker and Ballpoint Pen [] Safety Glasses (Required)

Phigenics Analytical Services Laboratory 3S701 West Ave, Suite 100 · Warrenville, IL 60555 844-850-4087 | phigenics.com Copyright©2021 Phigenics, LLC

LABEL SAMPLE CONTAINERS

Using a permanent marker, label the top of each bottle lid with the number that corresponds to the CoC "Field ID" for the specific sample location.

COLLECT WATER SAMPLE

IMPORTANT: Gloves and safety glasses are required to be worn.
Fill 250 mL sterile sample bottle to neck of bottle with water from source to be tested. Close bottle tightly and briefly shake (5-10 seconds) to dissolve neutralizing powder.

APPLY SECURITY SEALS and COMPLETE COC

Apply security seal to 250 mL sample bottle over side of cap to side of container exactly as shown. A signed and complete CoC is required for all samples submitted.

Using a ballpoint pen, fill out the CoC with specific sample location information. Include the sample ship date and sign in the "Relinquished By" box at the bottom of the page.

REPACK and SHIP on SAME DAY

For assurance of safety in shipping, repack water sample bottle upright (lid up) in sample box as shown in the photo. Place signed and complete CoC in the sample box. Replace top foam layer securely over contents. Close and seal lid with packing tape. Attach Priority Overnight shipping label.



250 mL Water Sample Bottles